

43 kinds of voice Dial switch instructons

Serial Number	Code (654321) ON is 1	Tone Type	Frequency	Description
Type0	000000	stop	0-0	stop
Type1	000001	alternating	800-970	2 Hz (250 ms-250 ms)
Type2	000010	rising	800-970	7 Hz (7/s)
Type3	000011	rising	800-970	1 Hz (1/s)
Type4	000100	continuous	2850-2850	
Type5	000101	rising	2850-2850	7 Hz
Type6	000110	rising	2400-2850	1 Hz
Type7	000111	rising and pulse	500-1200	3 sec., then 0.5 sec. OFF, then repeat
Type8	001000	falling	1200-500	falling in 1 Hz stroke
Type9	001001	alternating	2400-2850	2 Hz (250 ms-250 ms)
Type10	001010	pulse	970-0	0,5 Hz (1 sec. ON / 1 sec. OFF)
Type11	001011	alternating	800-970	1 Hz (500 ms-500 ms)
Type12	001100	pulse	2850-0	0,5 Hz (1 sec. ON / 1 sec. OFF)
Type13	001101	pulse	970-0	0,8 Hz (250 ms ON / 1 sec. OFF)
Type14	001110	continuous	970	
Type15	001111	alternating	554-440	100 ms-400 ms
Type16	010000	pulse	660-0	3,3 Hz (150 ms ON / 150 ms. OFF)
Type17	010001	pulse	660-0	0,28 Hz (1,8 sec. ON / 1,8 sec. OFF)
Type18	010010	pulse	660-0	0,05 Hz (6,5 sec. ON / 13 sec. OFF)
Type19	010011	continuous	660-0	
Type20	010100	alternating	554-440	0,5 Hz (1 sec. ON / 1 sec. OFF)
Type21	010101	pulse	660-0	1 Hz (500 ms-500 ms)
Type22	010110	pulse	2850-0	4 Hz (150 ms ON / 100 ms OFF)
Type23	010111	rising	800-970	50 Hz
Type24	011000	rising	2400-2850	50 Hz
Type25	011001	Xthree	970-0	3x500 ms. pulse, 1.5 sec. silence, then repeat
Type26	011010	Xthree	2850-0	3x500 ms. pulse, 1.5 sec. silence, then repeat
Type27	011011	continuous	4000-0	
Type28	011100	alternating	800-970	2 Hz (250 ms-250 ms)
Type29	011101	alternating	990-650	2 Hz (250 ms-250 ms)
Type30	011110	alternating	510-610	2 Hz (250 ms-250 ms)
Type31	011111	rising	300-1200	1 Hz
Type32	100000	alternating	2000-1200	
Type33	100001	Glocke	2000-1200	3x500 ms. pulse, 1.5 sec. silence, then repeat
Type34	100010	alternating	1000-2000	1 Hz (500 ms-500 ms)
Type35	100011	pulse	420-0	0,625 sec.
Type36	100100	rising and pulse	500-1200	rising 3.75 sec., then 0.25 sec. OFF
Type37	100101	rising and falling	1400-1600	rising 1 sec., falling 0.5 sec.
Type38	100110	rising and falling	500-1200	rising and falling over 3 sec.
Type39	100111	pulse	720-0	0,7 sec. ON, 0,3 sec. OFF
Type40	101000	rising and pulse	422-775	0.85 sec., 1 sec. silence, then repeat
Type41	101001	continuous	470-0	
Type42	101010	continuous	370-0	
Type43	101011	rising		MS190 MOTOR SIREN